

DOPPIO FLOOR CARE GUIDE



You will need

- 1 bucket
- Mop
- Wood Floor Soap

Cleaning and Care in one

- 1 Shake Wood Floor Soap well
- 2 Fill empty bucket with warm water
- 3 Add the appropriate Wood Floor Soap to the bucket (125ml Soap to 5 Lt water).
- 4 Place the mop into the soapy water & wring out well. Mop the floor & ensure not to apply too much water and do not leave puddles.

Important Notes

Use Wood Floor Soap for EVERY damp mopping. Once a week in the first month after installation, later as required.

- DO NOT use other cleaning agents
- DO NOT let water puddle on the floor
- DO NOT use water alone

Insider Tips

- The floor can be vacuumed or swept as required. After any spillage it is recommended that the area be mopped with Wood Floor Soap as per instructions.

Metal & other materials on wood

Attach felt gliders to table and chair legs to avoid scratches or oxidation of metal. Use white or beige felt. Do not use coloured felt as it could rub off into the timber. Do not place flowerpots directly on the floor as the moisture cannot escape & mould could form.

Hygrometer / Humidifier

To maintain the value of your oiled wood floor, a relative humidity of 40 - 50 % with a room temperature 21°C is required. During the winter months the air becomes less humid. Take precautions by using a humidifier.

Underfloor Heating/ Heating Period

Woodos does not recommend to use Doppio over under floor heating.